

Soothers™

Moisturizing Earplugs

NRR
33
dB

6680 Soothers
Uncorded



MOLDEX®
Ideas that wear well.™

HYDRATES AND MOISTURIZES FOR ALL DAY COMFORT

SOFT COMFORTABLE FIT

Moldex® Soothers foam earplugs are made of extra-soft, extra light foam. Their tapered shape fits easily in the ear canal, allowing them to seal gently and snugly without uncomfortable pressure. Plus, the outer surface of the earplug is smooth, so it doesn't irritate the ear canal. They're so comfortable you'll forget you're wearing earplugs.

INDEPENDENTLY TESTED: NRR 33

Soothers earplugs offer a high NRR 33, making them suitable for most noisy environments. So, while they look like fun, they provide serious protection.

FEATURES

- Hydrates and moisturizes for all day comfort.
- Soft foam and tapered shape for added comfort.
- Highest independently tested NRR 33 rating.
- Extra-soft, low-pressure foam for comfort and fit.
- Tapered shape for easy insertion and removal.
- Shaped to fit even very small ear canals.
- Non-irritating smooth surface.
- Look for the bright green color, and streaks and swirls as symbols of Moldex quality.
- 100% PVC-Free for a greener alternative.

Soothers™

Moisturizing Earplugs

PART # / DESCRIPTION	DISPLAY	CASE
6680 Soothers, Uncorded	200 Pairs per Box	10 Boxes per Case

ATTENUATION DATA

Tested According to ANSI Specs S3.19-1974 Michael & Assoc., State College, PA.

Frequency (Hz)	125	250	500	1000	2000	3150	4000	6300	8000		
Mean Attenuation (dB)	37.5	36.7	42.2	40.3	39.3	42.3	44.6	46.6	45.9	NRR 33	CSA AL
Standard Deviation (dB)	5.5	4.4	3.5	3.2	2.8	3.0	3.1	2.8	2.8		



MOLDEX-METRIC, INC.

10111 Jefferson Blvd.
Culver City, CA 90232
TEL: +1 (800) 421-0668 or
+1 (310) 837-6500
FAX: +1 (310) 837-9563
E-mail: sales@moldex.com
www.moldex.com

CANADIAN CUSTOMER SERVICE

Tel: +1 (800) 421-0668, Ext. 550/512
Fax: +1 (310) 837-9563

WARNING TO USER

1. Use this laboratory-derived attenuation data for comparison purposes only. The amount of protection afforded in field use often is significantly lower depending on how the protectors are fitted and worn.
2. Failure to follow all instructions could result in hearing loss or injury.
3. Failure to obtain a proper fit will reduce effectiveness of hearing protectors and could result in hearing loss or injury.
4. Soothers earplugs must only be used as part of a hearing conservation program that complies with applicable local safety and health regulations.
5. Overprotection can be dangerous. The wearer must be able to hear warning signals.
6. Wearers with hearing loss should exercise extreme caution.
7. It is the employer's responsibility to ensure that the type of hearing protector and its NRR is appropriate for the user in their particular workplace.
8. Failure to follow these warnings could result in serious injury or death.
9. If irritation, redness or discomfort occurs, discontinue use and consult a licensed health practitioner.

MOLDEX TECHNICAL ASSISTANCE

Moldex provides all of the technical assistance required to set up a hearing protection program. For more information call +1 (800) 421-0668 or +1 (310) 837-6500 ext. 512/550 or E-mail: tech@moldex.com or visit www.moldex.com.

Keep earplugs away from infants and small children as they may get caught in the windpipe and create a choking hazard.



DISTRIBUTED BY:



Printed on Recycled Paper

6680-900 REV B 10/18